


Double-sided textile frame, designed for freestanding and suspended use. Your textile print closes almost seamlessly in the corners to create a perfect, tight design. Various accessories can be applied in a simple way.

- Endless opportunities
- Perfect for exhibition stands
- Ideal to create large banners
- Textile print inside and outside
- Stabilizers for optimum reinforcement




Suspended from ceiling.

NF-04810




FK-0500 If the length of the frame is longer than 4 meters, an extension set (FK- 0500) is included.






FK-0220 When connecting the stabilizer, first place the lockset in the channel.




Then put the stabilizer (NF- 04438) on the lockset, now tighten the screw with the delivered allen key.




FK-0725 / FK-0726 / FK-0727 Endcap for all corners of the frame.



Place the endcap on top or bottom of the frame.





Place the textile print in the frame. Start with the corners and press the silicone strip in the channel

